

1

Fundamentals of Spectral Selectivity in Envelope Materials

Radiative exchange between buildings and their surrounding environment governs a substantial portion of energy use, thermal comfort, and indoor environmental quality. Unlike conductive or convective heat transfer, radiative processes are inherently spectral in nature: solar, atmospheric, and thermal radiation span wide wavelength ranges, each interacting with envelope materials in fundamentally different ways. The ability of a building envelope to selectively transmit, reflect, or absorb radiation as a function of wavelength—referred to as *spectral selectivity*—therefore represents a powerful and increasingly essential design lever in high-performance buildings.

This chapter establishes the foundational principles underlying spectral selectivity in envelope materials. It introduces the conceptual basis for wavelength-dependent control of radiative energy and situates spectral selectivity within the broader context of energy-efficient, resilient, and low-carbon building design. Particular emphasis is placed on understanding how shortwave solar radiation and longwave thermal radiation interact differently with envelope systems, motivating the need for distinct yet interconnected design strategies across the electromagnetic spectrum.

To support rigorous analysis and informed design, the chapter also develops the photometric and radiometric frameworks used to quantify spectral behavior and evaluate envelope performance. By linking physical radiation principles, human visual response, and building-scale performance metrics, this chapter provides the technical foundation required for subsequent discussions of advanced spectrally selective materials, systems, and applications in building envelopes.

1.1 Introduction to Spectral Selectivity

Spectral selectivity refers to the intentional differentiation of material–radiation interactions across the electromagnetic spectrum, enabling building envelope systems to respond differently to radiation at different wavelengths. In the building context, spectral selectivity is not an abstract optical concept, but a design-enabling strategy motivated by practical performance objectives, including energy efficiency, daylight utilization, thermal regulation, and environmental sustainability. The motivation for spectral selectivity arises from a fundamental mismatch between **broadband radiative sources** and **selective building performance demands**. Solar radiation, for example, arrives at building surfaces as a coupled mixture of ultraviolet, visible, and near-infrared energy. From a building use perspective, these spectral components serve distinct—and often competing—roles: visible radiation supports daylighting and

visual comfort, while near-infrared radiation contributes primarily to heat gain. Similarly, buildings continuously exchange thermal radiation with the surrounding environment across a broad range of infrared wavelengths, influencing heat retention, heat dissipation, and cooling potential. Because these radiative components are inherently mixed in natural sources, achieving differentiated building responses requires wavelength-specific control.

Historically, early building materials exhibited largely broadband radiative behavior, with limited capacity to distinguish between spectral regions. Initial attempts at solar control relied on tinted or reflective surfaces, which reduced total solar transmission but often compromised daylight quality and visual comfort. The development of spectrally selective materials marked a shift away from such trade-offs, enabled by advances in materials science, thin-film coatings, and surface engineering. Low-emissivity coatings, solar-control glazing, reflective façade finishes, and radiative cooling surfaces exemplify how wavelength-dependent optical properties can be engineered to meet specific building performance goals.

1.1.1 Spectral Selectivity in Energy-Efficient Building Design

From an application standpoint, spectral selectivity has become a critical tool in energy-efficient building engineering because it directly addresses one of the central challenges of envelope design: the need to manage multiple, often competing, radiative functions using passive means. Building envelopes must simultaneously regulate solar heat gain, thermal losses, daylight admission, and radiative heat exchange with the surrounding environment. Conventional broadband materials tend to link these functions together, limiting the designer's ability to optimize one objective without negatively affecting another. Spectrally selective envelope systems enable wavelength-dependent control over radiative transfer, allowing different portions of the spectrum to be managed according to their dominant energy and comfort impacts. By selectively transmitting visible radiation while reflecting or absorbing near-infrared radiation, envelope systems can reduce cooling loads without sacrificing daylight availability [1]. Similarly, selective control over longwave thermal radiation enables envelopes to either retain heat under cold conditions or dissipate heat under warm conditions [2]. These capabilities are especially valuable in high-performance buildings, where incremental improvements in envelope behavior can lead to disproportionately large reductions in operational energy use due to tighter overall energy budgets and reduced mechanical system capacity.

Importantly, spectral selectivity does not operate as a standalone solution, but as an enabling layer that enhances the effectiveness of other design strategies. When combined with optimized geometry, insulation, ventilation, and control systems, spectrally selective envelopes contribute to integrated energy solutions that reduce peak loads, improve system efficiency, and extend the operational envelope of passive design approaches.

1.1.2 Role in Thermal and Optical Energy Management

A defining advantage of spectral selectivity is its ability to support thermal and optical energy management simultaneously, rather than treating them as separate design problems. In building envelopes, optical performance—such as daylight transmission and glare control—is closely tied to shortwave radiation in the visible spectrum, while thermal performance is influenced by both shortwave solar heat gain and longwave thermal exchange.

Broadband approaches often force trade-offs between these domains. For example, reducing solar heat gain through uniformly absorptive or reflective materials can diminish indoor illuminance and degrade visual comfort. Spectral selectivity allows these competing objectives to be decoupled by acting directly on the spectral composition of radiation. Envelope systems can be designed to admit radiation that contributes to useful visual or thermal functions, while rejecting or dissipating radiation that primarily imposes thermal penalties. From an engineering perspective, this decoupling expands the feasible design space. It allows performance targets for daylighting, cooling, heating, and visual comfort to be addressed in parallel rather than sequentially. As a result, spectral selectivity serves not only as a performance enhancement strategy but also as a design simplification mechanism, reducing the need for compensatory mechanical or control interventions.

1.1.3 Indoor Comfort, Human Experience, and Passive Performance

Beyond aggregate energy metrics, spectral selectivity contributes directly to indoor comfort and occupant experience. The spectral composition of transmitted and reflected radiation influences perceived brightness, color rendering, glare potential, and thermal sensation [3]. By shaping which wavelengths reach interior spaces, envelope systems can improve visual comfort while maintaining thermal stability. In opaque envelope components, longwave spectral behavior plays a particularly important role in thermal comfort. Surface temperatures of walls, roofs, and façades affect mean radiant temperature, which is a key determinant of occupant thermal perception. Spectrally selective control of longwave emission can therefore influence comfort even when air temperature remains unchanged. Additionally, enhanced longwave emission under appropriate environmental conditions enables passive radiative cooling, reducing surface temperatures and mitigating overheating without mechanical energy input.

These interactions illustrate that spectral selectivity operates at the intersection of physical performance and human experience. Its benefits extend beyond energy savings to include improved comfort, reduced thermal asymmetry, and more stable indoor environments—outcomes that are increasingly prioritized in high-performance and occupant-centered building design.

1.1.4 Sustainability, Decarbonization, and Renewable Energy Alignment

At a broader scale, spectrally selective materials contribute to sustainability and decarbonization by enabling buildings to rely more heavily on passive radiative processes and less on energy-intensive mechanical systems. By reducing heating and cooling demand through selective radiative control, envelope systems lower operational energy consumption and associated carbon emissions over the building lifecycle [4]. Spectral selectivity also supports more effective utilization of renewable and ambient energy pathways. Selective interaction with solar radiation enables improved integration of daylighting and solar energy strategies, while selective longwave emission facilitates heat exchange with the ambient environment and the sky. These processes leverage naturally available energy flows rather than converting energy through mechanical or electrical systems, aligning with low-carbon design principles.

Crucially, many spectrally selective strategies are realized through material and surface-level design, without requiring additional operational energy or complex control logic. This passive nature enhances reliability, provides retrofit opportunities, reduces maintenance requirements, and improves long-term performance robustness—factors that are central to sustainable building deployment at scale.




Fig. 1.1 Standard terrestrial reference spectrum and blackbody spectra at 25 °C (it is calculated from Planck's law).

1.1.5 Shortwave and Longwave Spectral Selectivity: A Unified Design Framework

From the perspective of solar and environmental radiation, spectral selectivity in buildings can be broadly organized into two major categories: **shortwave selectivity** and **longwave selectivity**. This classification reflects differences in spectral range, dominant energy pathways, and design objectives, rather than distinct physical principles. As illustrated in Fig. 1.1, shortwave selectivity primarily addresses the ultraviolet, visible, and solar infrared portions of the terrestrial solar spectrum ($\approx 0.3\text{--}4\text{ }\mu\text{m}$), where incoming radiation governs daylight availability, solar heat gain, and photovoltaic conversion. In contrast, longwave selectivity operates in the thermal infrared range ($\approx 4\text{--}25\text{ }\mu\text{m}$), where building surfaces exchange heat with the surrounding environment through emission to the sky and absorption of atmospheric radiation, directly influencing radiative cooling and thermal balance.

In particular, shortwave selectivity governs interactions with incoming solar radiation, encompassing ultraviolet, visible, and near-infrared wavelengths. Design objectives in this regime include managing solar heat gain, maximizing useful daylight, controlling glare, and protecting materials and occupants from excessive ultraviolet exposure. Because these spectral components are inherently coupled in sunlight, selective control is essential for achieving differentiated performance outcomes. Longwave selectivity governs thermal radiation emitted by building surfaces and exchanged with the surrounding environment. Design objectives in this regime include heat retention, passive cooling, and regulation of nighttime energy balance. Selective longwave behavior determines whether thermal energy is conserved within the building or dissipated to the environment, particularly under clear-sky conditions where atmospheric transparency plays a critical role.

Although shortwave and longwave selectivity correspond to different spectral regimes and building functions, they are unified by a common design logic: the need to manage broadband radiative sources in a way that aligns with selective building performance requirements. Understanding this shared logic provides a coherent foundation for the detailed physical mechanisms, structural strategies, and performance analyses developed in the subsequent chapters.

In this book, spectral selectivity is treated as a façade- and envelope-scale concept rather than a property confined to specific components such as windows. Any envelope element that interacts with

radiation—transparent, translucent, or opaque—can exhibit spectral selectivity if its radiative properties vary meaningfully with wavelength. This use-driven and spectrum-centered perspective provides the foundation for the subsequent chapters, which examine how spectral selectivity is realized through physical mechanisms, structural strategies, and building-scale performance outcomes.

1.2 Photometric and Radiometric Basics

Radiation interacting with building envelopes plays a dual and inseparable role. It is simultaneously a carrier of physical energy that governs thermal exchange and a perceptual stimulus that shapes visual experience, comfort, and spatial quality. Any rigorous discussion of spectral selectivity must therefore engage with both aspects. Radiometric and photometric frameworks provide the complementary metric systems through which these roles are quantified and interpreted.

Radiometry describes electromagnetic radiation strictly in terms of physical energy and power, independent of any observer. It applies across the full electromagnetic spectrum relevant to buildings, including ultraviolet, visible, near-infrared, and thermal infrared radiation. Radiometric quantities form the physical basis for evaluating solar heat gain, thermal emission, radiative cooling, and energy exchange between buildings and their surrounding environment. Photometry, by contrast, quantifies radiation according to the wavelength-dependent sensitivity of the human visual system. It applies only to the visible portion of the spectrum and translates physical radiation into measures of perceived brightness, illumination, and visual comfort. In the built environment, photometry provides the essential link between envelope behavior and occupant experience, enabling assessment of daylight availability, glare, and visual quality.

In building envelopes, these two descriptions of radiation cannot be treated independently. The same incident solar radiation contributes simultaneously to thermal loads and daylighting; the same envelope surface that emits thermal radiation influences both energy balance and mean radiant temperature perceived by occupants. Spectral selectivity becomes meaningful precisely because radiometric and photometric responses to radiation are not uniform across wavelength. The envelope functions as a spectral filter that mediates between physical energy flows and perceptual outcomes.

For this reason, radiometry and photometry are developed in this section as parallel and interdependent frameworks rather than isolated domains. Before introducing their individual quantities and applications, it is useful to first establish the formal relationship that links them.

1.2.1 Photometric–Radiometric Conversion Framework

Radiometric and photometric quantities describe the same underlying radiation field using different weighting principles. Radiometry preserves the spectral distribution of radiant energy, while photometry applies wavelength-dependent weighting to account for human visual sensitivity. The relationship between the two is therefore established through spectral weighting rather than direct unit conversion.

1.2.1.1 Human Visual Sensitivity as a Function of Wavelength

The recognition that human vision responds unevenly across the visible spectrum predates formal photometric systems and arose from early experimental observations in vision science and illumination

research. Long before standardized curves were established, it was evident that equal radiant power at different wavelengths did not produce equal sensations of brightness. This discrepancy motivated systematic investigations into the wavelength dependence of visual perception, particularly as electric lighting technologies began to emerge and demanded quantitative design tools. During the late nineteenth and early twentieth centuries, researchers conducted controlled psychophysical experiments in which observers compared the apparent brightness of monochromatic light sources at different wavelengths [5]. These studies consistently demonstrated a pronounced maximum sensitivity in the green region of the spectrum, with decreasing sensitivity toward both shorter and longer wavelengths. Although experimental methods varied, the collective outcome was the recognition that visual response could be represented by a continuous spectral weighting function rather than a uniform response across visible wavelengths.

As lighting engineering matured, the need for a common reference model led to the formalization of an average human visual sensitivity curve. This effort culminated in the adoption of a standardized photopic spectral sensitivity function by international lighting authorities in the early twentieth century. The resulting function, later denoted $V(\lambda)$, represented a consensus-based approximation of human brightness perception under typical daylight and indoor lighting conditions. Importantly, this curve was not intended to describe individual vision or color perception in detail, but rather to provide a practical engineering tool that could translate physical radiation into perceptually meaningful quantities. Fig. 1.2 presents the schematic illustration of the historical evolution of photopic visual sensitivity functions. Early representations were derived from limited psychophysical data and emphasized narrow-field brightness matching. The International Commission on Illumination (CIE) 1931 photopic observer formalized a standardized spectral sensitivity function that became the basis of photometry and colorimetry. Subsequent refinements broadened the effective sensitivity range to better represent large-field viewing




Fig. 1.2 Schematic illustration of the historical evolution of photopic visual sensitivity functions.

and practical lighting conditions. The curves shown are illustrative and do not represent exact tabulated values defined by The International Commission on Illumination (CIE) standards.

Although the photopic luminous efficiency function is often treated as a fixed curve, its present form reflects a gradual process of experimental refinement and standardization. Fig. 1.2 illustrates, in schematic form, how early brightness-based sensitivity representations evolved into the standardized CIE photopic observer and later refinements. The overall structure of the curve has remained stable, while its detailed shape has been adjusted to improve consistency with experimental observation and practical lighting conditions [5].

In photometry, $V(\lambda)$ serves a specific and deliberate purpose: it weights spectral radiation according to perceived brightness, not color appearance. When combined with a scaling constant, this weighting enables the conversion of spectral radiant quantities into luminous quantities that correlate with human brightness perception. In this sense, photometry can be understood as **spectrally weighted radiometry**, where the weighting reflects biological response rather than physical energy equivalence. When coupled with color science, the photopic sensitivity function forms a cornerstone of modern lighting theory. The same experimental foundations that led to $V(\lambda)$ also informed the development of color-matching functions and standardized color spaces. Together, these frameworks established the basis for describing brightness, color, and illumination in a unified and quantitative manner. In building engineering, this integration underlies virtually all lighting and daylighting principles, from illuminance criteria and luminance-based glare assessment to daylight availability metrics and visual comfort evaluation.

For building envelopes, the implications are particularly significant. Envelope systems mediate the spectral composition of daylight entering interior spaces, influencing both the total amount of visible radiation and its distribution across wavelengths. Because perceived brightness depends on spectral weighting rather than total radiant energy, envelope materials can be engineered to preferentially transmit visually efficient wavelengths while attenuating others. This capability is central to spectral selectivity: it allows visual performance to be preserved or enhanced without a proportional increase in radiant energy transmission and associated thermal load.

Thus, human visual sensitivity as a function of wavelength provides not only the physiological basis for photometry but also the conceptual foundation for decoupling visual and thermal objectives in envelope design. By exploiting the mismatch between energetic significance and perceptual effectiveness across the spectrum, spectrally selective envelopes align building lighting and daylighting performance with energy efficiency and comfort goals.

1.2.1.2 Mechanical Equivalent of Light K_m : Historical and Physical Basis

The mechanical equivalent of light, commonly denoted K_m , did not originate as an abstract constant or an arbitrary definition. Rather, it emerged from a prolonged effort to reconcile perceptual units of light with physically measurable quantities, driven by the practical needs of illumination engineering and the maturation of radiation physics. Its development reflects a sequence of conceptual and metrological transitions, beginning with candle-based photometry, progressing through thermodynamic radiation standards, and culminating in the modern radiometric definition of photometric units.

In the nineteenth century, light was quantified almost exclusively through photometric units derived from candles and flame lamps. These units—such as the British standard candle, the Carcel lamp, and the Hefner lamp—were defined by specific fuels, geometries, and burning conditions. While adequate

for early lighting practice, they suffered from fundamental limitations: they were difficult to reproduce, sensitive to environmental conditions, and lacked any direct connection to radiometry-related physical quantities such as energy or power. As electric lighting technologies emerged and international comparisons became necessary, these deficiencies became increasingly problematic.

A critical conceptual shift occurred when photometry began to draw upon advances in thermal radiation theory. By the late nineteenth century, the laws governing blackbody radiation were well established, culminating in Planck's formulation at the turn of the twentieth century. This opened the possibility of defining light not by a particular lamp, but by the radiation emitted from a body at a known thermodynamic state. Among candidate materials, platinum proved especially suitable because of its chemical stability and its sharply defined freezing (solidification) temperature. A platinum radiator at this temperature behaves in a reproducible manner and emits radiation whose spectral distribution can be calculated from first principles.

This insight led to the replacement of flame-based standards with a blackbody-based photometric reference. The central move was to anchor "brightness" to a Planck (blackbody) radiator at a well-defined thermodynamic temperature. In 1946, the International Committee for Weights and Measures (CIPM) promulgated a definition of the "new candle" that directly uses a full radiator at the temperature of solidification (freezing) of platinum (at the temperature ~ 2041 K): *the brightness (luminance) of that full radiator is 60 new candles per square centimeter in the perpendicular direction*. In this system, the photometric scale was anchored by specifying the luminance of such a radiator—effectively fixing the perceptual brightness of a known thermodynamic source. At this stage, the unit of light was still expressed in candle-based terms, but the candle itself had been transformed from a chemical artifact into a physically realizable radiation standard.

Once luminous intensity was tied to a platinum blackbody at the fusion temperature, a crucial procedural step became possible. The spectral radiance of the platinum radiator could be calculated using Planck's law, yielding the radiant power distribution as a function of wavelength. Independently, psychophysical experiments had already established the relative spectral sensitivity of the human eye under photopic conditions, later standardized as the luminous efficiency function $V(\lambda)$. By weighting the calculated spectral radiance of the platinum blackbody with this visual sensitivity function and integrating over wavelength, engineers could compute the photometric output associated with a known radiant power. In other words, for that platinum-point radiator, one can write a relationship of the form:

$$X_v = K_m \int X_{e,\lambda}(\lambda, T) V(\lambda) d\lambda \quad (1.1)$$

where X_v is the (visual) photometric luminance assigned by the platinum "60 new candle" definition, and the integral is computed from Planck's law for the radiant power $X_{e,\lambda}$ of platinum at the temperature 2041 K and the standardized $V(\lambda)$. In this historical framework, K_m appears naturally as the proportionality factor that makes the computed, vision-weighted radiometric quantity match the defined photometric quantity of the platinum radiator. Upon resolving Eq. (1.1), K_m can be obtained as approximately 683.

However, it is equally important to understand what happened next, because it explains the appearance of **1/683**. By the 1970s, realizing a high-temperature Planck radiator in routine metrology practice was difficult, while radiometric power measurement had become far more precise. For this reason, the 16th CGPM (CIPM, the International Committee on Weights and Measures) replaced (abrogated) the platinum-point definition and redefined the candela radiometrically, by specifying monochromatic radiation at frequency 540×10^{12} Hz and a radiant intensity of $1/683$ W/sr [6]. The mechanical equivalent

of light is therefore no longer an experimentally determined quantity, but a defining constant embedded within the standard metrics. Nevertheless, its numerical value remains rooted in the earlier procedure that linked candle-based photometry, platinum blackbody radiation, Planck's law, and human visual sensitivity. From a conceptual standpoint, the historical development of K_m reveals the hybrid nature of photometry. Unlike purely physical constants, it embodies both a biological component—the spectral response of human vision—and a metrological choice aimed at ensuring continuity and practicality. This dual origin explains why photometric quantities cannot be interpreted solely in energetic terms, and why spectral weighting is indispensable when converting between radiometric and photometric measures. In the context of building engineering and spectral selectivity, the mechanical equivalent of light thus represents the formal bridge between energy-based radiation analysis and perception-based lighting evaluation.

1.2.1.3 Photometric–Radiometric Conversion Framework

Radiometric and photometric quantities describe the same underlying radiation field using different weighting principles. Radiometry preserves the spectral distribution of radiant energy, while photometry applies wavelength-dependent weighting to account for human visual sensitivity. The relationship between the two is therefore established through spectral weighting rather than direct unit conversion.

For a given generic spectral radiometric quantity $X_e(\lambda)$, the corresponding photometric quantity X_v is obtained by weighting the spectral distribution with the photopic luminous efficiency function $V(\lambda)$ and scaling by the mechanical equivalent of light K_m in Eq. (1.2). $K_m = 683 \text{ lm/W}$ corresponds to the maximum luminous efficacy at the peak of visual sensitivity ($\sim 555 \text{ nm}$).

$$X_v = K_m \int_{380}^{780} X_e(\lambda) V(\lambda) d\lambda \quad (1.2)$$

This expression formalizes a central principle for spectrally selective building envelopes: radiation that is energetically significant is not necessarily perceptually significant, and radiation that is perceptually efficient may carry relatively little radiant energy. Near-infrared radiation, for example, contributes strongly to radiant energy and thermal load while contributing negligibly to photometric quantities. Conversely, visible radiation near the peak of $V(\lambda)$ contributes efficiently to perceived brightness with comparatively modest radiant energy.

In architectural engineering, this conversion framework provides the quantitative basis for evaluating how building envelopes simultaneously mediate energy flows and visual conditions. Envelope materials are continuously exposed to broadband solar and environmental radiation, yet their performance is often judged using a mixture of radiometric metrics (such as solar heat gain and thermal radiation exchange) and photometric metrics (such as daylight illuminance and luminance). Equation (1.2) clarifies that these metrics are not interchangeable: the same spectral radiation field can produce markedly different energetic and perceptual outcomes depending on how its spectral content aligns with human visual sensitivity.

This distinction is particularly important for the design and assessment of spectrally selective envelope materials. Glazing systems, coatings, and shading devices that attenuate near-infrared radiation can significantly reduce cooling loads without proportionally reducing perceived daylight, because near-infrared wavelengths contribute little to photometric quantities. Conversely, selective transmission or redirection of radiation within the visible spectrum—especially near the peak of $V(\lambda)$ —can enhance

daylight availability and visual comfort with relatively small increases in radiant energy entering the space. The photometric–radiometric conversion framework, therefore, enables designers to distinguish between energy-efficient and visually efficient spectral bands and to exploit this distinction intentionally.

From a performance-analysis perspective, Eq. (1.2) also explains why envelope metrics such as visible transmittance, solar heat gain coefficient (SHGC), and daylight illuminance cannot be inferred from one another without spectral information. Two envelope systems with identical visible transmittance may differ substantially in their radiometric impact if their transmitted spectra are weighted differently outside the visible range, while two systems with similar solar heat gain may produce very different visual environments depending on their spectral alignment with $V(\lambda)$. The conversion framework thus motivates the use of spectrally resolved material properties in envelope modeling rather than broadband averages alone.

More broadly, the photometric–radiometric relationship embedded in Eq. (1.2) positions the building envelope as a spectral mediator between environmental radiation and human experience. By shaping the spectral distribution of transmitted, reflected, or absorbed radiation, envelope systems can decouple visual performance from thermal impact and enable passive strategies that simultaneously support daylighting quality, thermal comfort, and energy efficiency. This perspective underlies many advanced envelope concepts discussed in subsequent chapters, including spectrally selective glazing, transparent photovoltaics, and multifunctional façade systems designed to manage shortwave and longwave radiation in distinct yet coordinated ways.

1.2.2 Paired Radiometric and Photometric Quantities

Radiometric and photometric quantities form two parallel measurement systems that describe the same radiation field from different perspectives. Radiometry quantifies electromagnetic radiation strictly in terms of physical energy and power, independent of human perception. Photometry, by contrast, quantifies radiation as weighted by the spectral sensitivity of the human visual system and therefore applies only to the visible portion of the spectrum. As established in Section 1.2.1, the two systems are formally linked through spectral weighting and the mechanical equivalent of light. As a result, most fundamental quantities in radiometry have direct photometric counterparts.

Despite this one-to-one correspondence, radiometric and photometric quantities are not interchangeable in practice. They are used to answer different questions in architectural engineering. Radiometric quantities govern thermal loads, solar heat gain, radiative exchange, and energy balance across building envelopes, while photometric quantities govern daylight availability, brightness perception, glare, and visual comfort. Understanding both the pairing and the distinction between these quantities is essential for spectrally selective envelope design, where energetic and perceptual objectives must often be optimized simultaneously. Table 1.1 summarizes the principal paired radiometric and photometric quantities relevant to building envelopes.

1.2.2.1 Radiant and Luminous Energy

Radiant energy, denoted by Q_e , represents the total electromagnetic energy carried by radiation. It is measured in joules (J) and is the most fundamental radiometric quantity. Its photometric counterpart, luminous energy Q_v , represents the time-integrated perceptual effect of visible radiation as weighted by human visual sensitivity. For radiation at a given wavelength λ , the spectral radiant energy $Q_{e,\lambda}$ can be

Table 1.1 Paired radiometric and photometric quantities.

Physical meaning	Radiometric quantity (subscript e)	Unit	Photometric quantity (subscript v)	Unit
Energy	Radiant energy (Q_e)	J	Luminous energy (Q_v)	lm·s
Power	Radiant flux (Φ_e)	W	Luminous flux (Φ_v)	lm
Power per area	Irradiance (E_e)/	W/m ²	Illuminance (E_v)/	lx (lm/m ²)
	Radiant exitance (M_e)		Luminous exitance (M_v)	
Power per solid angle	Radiant intensity (I_e)	W/sr ¹	Luminous intensity (I_v)	cd (lm/sr ¹)

expressed as the product of the number of photons n_λ and the energy of an individual photon q_λ , such that,

$$Q_e, \lambda = n_\lambda q_\lambda [J] \quad (1.3)$$

where the photon energy is given by Planck's relation $q_\lambda = hc/\lambda$. This expression makes explicit the wavelength dependence of photon energy: photons at shorter wavelengths carry more energy per photon than those at longer wavelengths. Then, the total radiant energy Q_e associated with a radiation field is obtained by integrating the spectral radiant energy over all wavelengths.

$$Q_e = \int_0^\infty Q_\lambda d\lambda [J] \quad (1.4)$$

This formulation highlights that radiant energy is fundamentally a spectral quantity, and that the same total radiant energy may be distributed across wavelengths in very different ways. For a fixed amount of spectral radiant energy, the number of photons required depends inversely on wavelength. Because photon energy increases as wavelength decreases, shorter-wavelength radiation requires fewer photons to deliver the same radiant energy, whereas longer-wavelength radiation requires a larger number of lower-energy photons. This relationship is central to understanding why radiation with identical radiant energy content can have markedly different physical and perceptual effects depending on its spectral distribution.

The photometric counterpart to radiant energy is luminous energy Q_v , which represents the time-integrated perceptual effect of visible radiation. Luminous energy is derived by weighting the spectral radiant energy by the photopic luminous efficiency function $V(\lambda)$ and scaling by the mechanical equivalent of light K_m , by following Eq. (1.2). Unlike radiant energy, luminous energy depends not only on the total energy content but also on how effectively photons at each wavelength stimulate the human visual system. As a result, two radiation fields with identical radiant energy can differ substantially in luminous energy if their spectral distributions differ.

The photon-based perspective further clarifies this divergence. Although shorter-wavelength photons carry more energy individually, their contribution to luminous energy depends on their alignment with the peak of visual sensitivity. Radiation near the peak of $V(\lambda)$ produces a strong photometric response with comparatively modest radiant energy, whereas radiation outside the visible spectrum contributes

to radiant energy without producing any luminous energy at all. Photon count, radiant energy, and perceived brightness are therefore related but fundamentally distinct descriptors of radiation.

In building engineering practice, luminous energy itself is rarely used as an explicit design or performance metric. Envelope and daylighting analyses typically rely on instantaneous or time-averaged quantities—such as radiant flux, illuminance, and luminance—rather than on the cumulative perceptual quantity expressed in lumen-seconds. Temporal aspects of lighting performance are usually addressed through illuminance-based metrics evaluated over specified periods (e.g., daylight autonomy or annual daylight exposure), rather than through direct calculation of luminous energy. As a result, luminous energy primarily serves as a conceptual bridge that establishes formal symmetry between radiometric and photometric systems, rather than as a quantity reported in routine architectural analyses.

Nevertheless, understanding the distinction between radiant and luminous energy is essential for spectrally selective envelope design. Building envelopes are exposed to broadband solar radiation, where near-infrared wavelengths can dominate radiant energy and thermal load while contributing negligibly to luminous energy, and visible wavelengths near the peak of visual sensitivity can provide effective daylight with relatively low energetic impact. By selectively modulating the spectral distribution of transmitted, absorbed, or reflected radiation, envelope materials can decouple thermal performance from visual performance—an insight that underlies advanced glazing systems, daylight-optimized façades, and multifunctional envelope technologies discussed in later chapters.

1.2.2.2 Radiant and Luminous Flux

Radiant flux, denoted by Φ_e , describes the rate at which radiant energy is transferred and is expressed in watts (joules per second). Radiant flux may be expressed formally as the time rate of change of radiant energy:

$$\Phi_e = \frac{dQ_e}{dt} [\text{W}] \quad (1.5)$$

It represents how much electromagnetic energy is emitted, transmitted, reflected, or absorbed per unit time. Luminous flux Φ_v , measured in lumens, is the photometric counterpart that describes the rate at which radiation produces perceived brightness for the human visual system. The corresponding luminous flux is obtained by weighting the spectrum with the photopic luminous efficiency function $V(\lambda)$ and scaling by the mechanical equivalent of light, K_m :

$$\Phi_v = K_m \int_{380}^{780} \Phi_e(\lambda) V(\lambda) d\lambda [\text{lm}] \quad (1.6)$$

This equation is foundational for architectural engineering because it formalizes a practical truth: the same radiant power can produce very different perceived brightness depending on spectral composition, and large fractions of solar or lamp power may be “energetically real” yet “photometrically invisible” (e.g., near-infrared). Because flux quantities are rates, they are the natural currency of building performance modeling. In thermal analysis, the envelope is driven by incident and transmitted radiant flux (shortwave solar gains and longwave exchange), which governs cooling and heating loads. In daylighting analysis, the same envelope is evaluated using luminous flux and its spatial derivatives (illuminance and luminance), which govern daylight availability, glare risk, and visual comfort. This makes radiant and luminous flux a primary interface between energy simulation workflows and lighting/daylighting workflows.

In lighting engineering, the most widely used bridge between Φ_e and Φ_v is luminous efficacy, which quantifies how much luminous flux is produced per unit radiant power:

$$\eta_e = \frac{\Phi_v}{\Phi_e} [\text{lm/W}] \quad (1.7)$$

For a general polychromatic radiation field, Φ_e is the integral of the spectral radiant flux over all wavelengths, so luminous efficacy can be written explicitly in spectral form by combining the definitions:

$$\eta_e = \frac{K_m \int_{380}^{780} \Phi_e(\lambda) V(\lambda) d\lambda}{\int_0^\infty \Phi_e(\lambda) d\lambda} [\text{lm/W}] \quad (1.8)$$

This expression shows that luminous efficacy is not a universal constant; it is a spectral property. Radiation concentrated near the peak of $V(\lambda)$ yields high efficacy, whereas radiation outside the visible band contributes to the denominator (radiant power) but not the numerator (luminous flux), thereby lowering efficacy. At the wavelength of maximum photopic sensitivity, where $V(\lambda) = 1$ (near 555 nm), luminous efficacy reaches its maximum possible value: 683 lm/W. This is a theoretical maximum for radiation-to-vision conversion, not a statement about electrical lighting devices. Real spectra distribute power across wavelengths where $V(\lambda) < 1$, and many sources (including daylight and most lamps) also contain some non-visible power, so their η_e is necessarily lower.

Both radiant and luminous flux are widely used and essential in building engineering, but they serve distinct roles. Radiant flux governs energy transfer through the building envelope and is fundamental to thermal load calculations, solar heat gain analysis, and energy simulation. The solar radiation incident on a façade or transmitted through glazing is first quantified in radiometric terms to assess its contribution to heating and cooling demands. In this context, radiant flux directly influences heating, ventilation, and air conditioning (HVAC) sizing, peak load estimation, and annual energy consumption. Luminous flux, by contrast, is central to daylighting and lighting design. It quantifies the amount of visually effective light entering or generated within a space and forms the basis for illuminance calculations and lighting performance metrics. In envelope design, luminous flux transmitted through windows and skylights determines the potential for daylight utilization and affects visual comfort, occupant satisfaction, and lighting energy savings. Unlike radiant flux, luminous flux reflects how occupants perceive and use light rather than how the building exchanges energy.

The distinction between radiant and luminous flux is especially important for spectrally selective envelope systems. Two glazing products may transmit similar luminous flux while transmitting very different radiant fluxes if their spectral transmittance differs in the near-infrared region. In such cases, occupants experience similar daylight levels, but the building incurs different thermal loads. Conversely, materials that transmit high radiant flux concentrated in visible wavelengths may appear bright while contributing less to unwanted heat gain. Flux-based analysis, therefore, provides a direct quantitative framework for evaluating how envelope materials balance energy efficiency and daylight performance.

From a design and analysis perspective, radiant flux typically serves as an input to thermal models, while luminous flux serves as an input to visual and daylighting models. The paired treatment of these quantities allows building engineers to evaluate envelope performance across disciplines and to identify opportunities where spectral selectivity can reduce energy use without compromising visual quality. As such, radiant and luminous flux form one of the most practically significant bridges between radiometric physics and architectural performance.

1.2.2.3 Radiant and Luminous Flux Density

Radiant and luminous flux density describe the spatial concentration of optical radiation and are fundamentally defined in terms of flux density, rather than flux alone. Radiant flux, Φ [W], represents the total optical power emitted, transmitted, or received, while radiant flux density—commonly referred to as irradiance—quantifies how that power is distributed over a receiving surface. Irradiance is defined as the radiant flux per unit area, as Eq. (1.9), and represents the physically relevant measure governing energy transfer processes such as solar heat gain, absorption, and photothermal conversion in building envelopes. When spectral effects are important, irradiance is expressed in wavelength-resolved form as Eq. (1.10), allowing different spectral bands—ultraviolet, visible, and near-infrared—to be evaluated according to their distinct thermal and material interactions.

$$E_e = \frac{d\Phi_e}{dA} [W/m^2] \quad (1.9)$$

$$E_{e,\lambda} = \frac{d\Phi_{e,\lambda}}{dA} [W/m^2] \quad (1.10)$$

The luminous counterpart of radiant flux density is illuminance, which quantifies luminous flux density on a surface and incorporates the spectral sensitivity of the human visual system. Luminous flux, Φ_v [lm], is obtained by weighting the spectral radiant flux by the photopic luminous efficiency function, and illuminance is defined as:

$$E_v = \frac{d\Phi_v}{dA} [lx] \quad (1.11)$$

Unlike irradiance, illuminance reflects perceived brightness rather than physical energy, and wavelengths outside the visible range contribute negligibly despite potentially substantial energy content. As a result, irradiance and illuminance can vary independently for spectrally selective systems, even under identical geometric and boundary conditions.

For both radiant and luminous flux density, the incident angle between the radiation direction and the surface normal is governed by the cosine law, Eq. (1.12), which states that the effective flux density on a planar surface scales with the cosine of the incidence angle θ :

$$E_e = E_{e,0} \cos \theta, \quad E_v = E_{v,0} \cos \theta, \quad (1.12)$$

where $E_{e,0}$, $E_{v,0}$ represent the normal-incidence irradiance and illuminance, respectively. This geometric relationship arises from the projection of the receiving surface area relative to the direction of incoming radiation and forms the basis for directional solar gain calculations on façades, roofs, and inclined glazing systems. The cosine law is therefore implicitly embedded in solar position models, daylighting algorithms, and whole-building energy simulation tools.

In building engineering practice, radiant and luminous flux density serve complementary but distinct roles in envelope analysis and design. Irradiance is the primary quantity used in thermal modeling, informing calculations of SHGCs, cooling and heating loads, and the performance of envelope materials designed to regulate shortwave radiation. Illuminance, in contrast, is central to daylighting analysis and visual comfort assessment, supporting metrics such as daylight autonomy, glare potential, and lighting energy reduction. For advanced envelope systems—particularly spectrally selective and adaptive fenestration—the ability to decouple irradiance from illuminance is critical: reductions in radiant flux density, especially in the near-infrared range, can significantly lower thermal loads while maintaining

adequate luminous flux density for daylighting. Consequently, the joint evaluation of radiant and luminous flux density provides a unified framework for optimizing both energy efficiency and visual performance in high-performance building envelopes.

1.2.2.4 Radiant and Luminous Exitance

Radiant exitance, denoted by M_e , represents the radiant flux leaving a surface per unit area, which has a similar expression as Eq. (1.9):

$$M_e = \frac{d\Phi_e}{dA} [W/m^2] \quad (1.13)$$

Radiant exitance describes the total radiant power leaving a surface per unit area, regardless of direction. In the built environment, radiant exitance is especially relevant for understanding thermal emission from envelope components. Roofs, façades, and pavements continuously emit thermal radiation to the surrounding environment, influencing surface temperatures and nighttime heat balance. Radiant exitance provides a measure of how strongly a surface is releasing radiative energy. Surfaces with high longwave radiant exitance can dissipate heat more effectively, which is advantageous for passive cooling strategies under appropriate environmental conditions. Conversely, reducing radiant exitance may be desirable in cold climates to limit radiative heat loss. Longwave spectral selectivity directly affects radiant exitance by redistributing emitted energy across wavelength bands. This allows building surfaces to release thermal energy selectively, enhancing or suppressing radiative heat exchange depending on climatic and design objectives.

Luminous exitance, denoted by M_v , represents the luminous flux leaving a surface per unit area and is defined as:

$$M_v = \frac{d\Phi_v}{dA} [lm/m^2] \quad (1.14)$$

Luminous exitance characterizes the total visually effective light emitted, reflected, or transmitted by a surface, accounting for the spectral sensitivity of the human visual system. In building applications, luminous exitance is closely related to the perceived brightness of interior and exterior surfaces and plays an important role in daylight distribution, visual comfort, and glare formation. Envelope elements such as façades, interior finishes, and glazing systems influence the luminous environment not only through transmission but also through reflection and secondary emission. Surfaces with higher luminous exitance can contribute to improved daylight penetration and spatial brightness, potentially reducing reliance on electric lighting. However, excessive luminous exitance, particularly from highly reflective or specular surfaces, may increase glare risk and visual discomfort. Material reflectance, surface texture, and spectral characteristics collectively govern luminous exitance, allowing envelope design to balance visual performance with comfort and energy efficiency.

1.2.2.5 Radiance and Luminance

Radiance, denoted by L , provides a directional description of radiation. It is defined as radiant flux per unit projected area per unit solid angle, as shown in Eq. (1.15):

$$L_e = \frac{d^2\Phi_e}{dA \cos \theta d\Omega} [W/m^2 \cdot sr] \quad (1.15)$$

where $d\Omega$ is the differential solid angle and θ is the angle between the surface normal and the direction of radiation. Radiance describes the directional distribution of radiant energy and is conserved along a ray in lossless media, making it a fundamental quantity for analyzing directional radiation transport. In the built environment, radiance is particularly important for characterizing how solar radiation and thermal emission are distributed directionally by envelope components such as glazing, shading systems, and façade materials. High radiance in specific directions can lead to localized overheating, concentrated solar gains, or glare-related thermal discomfort near windows. For envelope materials with specular or directional properties, radiance provides a more complete description than irradiance alone, capturing how radiation is redirected, concentrated, or diffused by surface geometry and optical design.

Luminance, denoted by L_v , represents the luminous flux per unit projected area per unit solid angle and is defined as Eq. (1.16):

$$L_v = \frac{d^2\Phi_v}{dA \cos \theta d\Omega} [cd/m^2] \quad (1.16)$$

Luminance characterizes the directional brightness of a surface as perceived by the human visual system and is directly related to visual sensation. In building applications, luminance is a critical metric for evaluating visual comfort, glare risk, and the perceived brightness of envelope elements, light sources, and interior surfaces. Glazing systems, façades, and reflective materials can exhibit high luminance in certain viewing directions, potentially causing discomfort glare even when overall illuminance levels remain acceptable. Conversely, well-controlled luminance distributions can enhance visual comfort and spatial quality by avoiding excessive contrast and bright spots within the field of view. Surface reflectance, texture, and directional scattering properties all influence luminance, allowing envelope design to shape visual experience beyond simple light quantity metrics.

In building envelope engineering, radiance and luminance complement irradiance and illuminance by capturing the directional nature of radiation–surface interactions. While irradiance and illuminance quantify the total incoming flux density, radiance and luminance describe how that radiation is distributed across directions after interacting with envelope materials. This distinction is essential for analyzing glare from daylighting systems, concentrated solar reflections from façades, and directional thermal emission effects. By jointly considering radiance and luminance, envelope design can manage both energy flows and visual comfort, ensuring that radiation is not only limited in magnitude but also distributed in directions that support thermal performance and occupant well-being.

1.2.2.6 Radiant and Luminous Intensity

Radiant intensity, denoted by I_e , represents the radiant flux emitted by a source per unit solid angle in a given direction and is defined as Eq. (1.17):

$$I_e = \frac{d\Phi_e}{d\Omega} [W/sr] \quad (1.17)$$

Radiant intensity characterizes how strongly a radiation source emits energy in specific directions, independent of distance from the source. Unlike irradiance or radiance, which are surface-based quantities, radiant intensity is a source-based directional property and is particularly useful for describing compact or quasi-point radiation sources. In the built environment, radiant intensity is relevant for characterizing solar position–dependent emission from the sun, as well as the directional output of artificial thermal or photothermal devices. The directional nature of radiant intensity governs how radiation is distributed

toward building envelopes, influencing localized solar exposure, shading effectiveness, and the angular dependence of incident irradiance on façades and roofs.

Luminous intensity, denoted by I_v , represents the luminous flux emitted by a source per unit solid angle and is defined as Eq. (1.18):

$$I_v = \frac{d\Phi_v}{d\Omega} [cd] \quad (1.18)$$

Luminous intensity describes the directional strength of a light source as perceived by the human visual system and is expressed in candela. In building applications, luminous intensity is a fundamental descriptor of electric lighting systems and daylight sources, governing how light is distributed within spaces and toward building surfaces. The angular luminous intensity distribution of luminaires directly affects illuminance levels, glare potential, and lighting uniformity in interior environments. For façade lighting and exterior illumination, luminous intensity determines how light propagates toward observers and adjacent buildings, influencing visual comfort, light pollution, and compliance with lighting regulations.

In building engineering and envelope design, radiant and luminous intensity serve as foundational descriptors linking radiation sources to surface-based quantities such as irradiance, radiance, and illuminance. The angular distribution of radiant intensity from the sun or artificial sources determines how energy is delivered to envelope surfaces, while the luminous intensity distribution of lighting systems shapes the visual environment experienced by occupants. By controlling radiant and luminous intensity through source design, optical elements, and shading strategies, building systems can manage both energy input and visual performance, ensuring that radiation is delivered in directions that support thermal efficiency, visual comfort, and environmental quality.

1.2.2.7 Lambertian and Specular Surfaces

The distinction between Lambertian and specular surfaces describes how radiation is redistributed after interacting with a material surface and is fundamental to both radiometric and photometric analyses. Fig. 1.3 presents the basic features of these two types of surfaces.




Fig. 1.3 Surface types—Lambertian and specular.




Fig. 1.4 Radiance (luminance) and radiant (luminous) intensity characteristics of a Lambertian surface.

In particular, a **Lambertian surface** is defined as an ideal diffuse emitter or reflector whose radiance is independent of viewing direction. For such a surface, the radiance remains constant for all observation angles, and the directional distribution of emitted or reflected radiation follows a cosine law with respect to the surface normal. As a result, the radiant intensity varies proportionally with $\cos \theta$, while radiance remains invariant (as shown in Fig. 1.4). This property leads to a direct relationship between radiance and exitance for a Lambertian surface, as Eq. (1.19).

$$M = \pi L \quad (1.19)$$

These relationships greatly simplify the description of radiation exchange and are widely assumed in building simulation tools, daylighting models, and thermal radiation calculations.

In contrast, a specular surface reflects or emits radiation preferentially in specific directions determined by geometric optics, following the law of reflection. For specular behavior, radiance and luminance are strongly direction dependent, and no simple proportional relationship exists between exitance and radiance. Instead, radiation is concentrated into narrow angular ranges, leading to high radiance or luminance in specific directions while remaining low elsewhere. From a radiometric perspective, this directional concentration can produce localized peaks in irradiance or radiance even when total radiant flux or exitance remains moderate. From a photometric perspective, specular surfaces can generate very high luminance values in particular viewing directions, which is a primary mechanism behind glare and visual discomfort.

In the built environment, many common materials approximate Lambertian behavior, including matte paints, rough concrete, brick, textiles, and vegetation. These surfaces redistribute incident radiation broadly and uniformly, producing smooth spatial distributions of radiance and luminance. As a result, Lambertian-like surfaces are often preferred for interior finishes and urban pavements, as they promote visual comfort, reduce glare, and support uniform daylight distribution. Thermally, diffuse longwave emission from Lambertian surfaces enables predictable radiative heat exchange with the surrounding environment, which is advantageous for passive cooling analysis and nighttime heat dissipation modeling.

Specular and semi-specular surfaces are equally prevalent and play a distinct role in building envelopes. Glass façades, polished metals, coated glazing, and reflective membranes exhibit strong directional behavior, particularly in the solar and visible spectra. Specular reflection from glazing can redirect solar radiation deep into interior spaces, enhancing daylight penetration under controlled conditions, but can also produce concentrated solar reflections that increase cooling loads or cause discomfort to pedestrians and neighboring buildings. High-luminance reflections from specular surfaces are a well-documented cause of glare, even when overall illuminance levels remain within acceptable ranges. In thermal applications, specular behavior in the longwave range can suppress or redirect radiative heat loss, influencing surface temperatures and envelope energy balance.

Most real-world building materials fall between the Lambertian and specular extremes and exhibit mixed or anisotropic scattering behavior. Advanced envelope systems increasingly exploit this intermediate regime by tailoring surface roughness, microstructure, or coatings to shape angular radiation distributions deliberately. Examples include prismatic daylight-redirecting elements, low-emissivity coatings with directional selectivity, and façade systems designed to reflect high-angle summer sun while admitting low-angle winter radiation. Understanding the radiometric and photometric differences between Lambertian and specular surfaces therefore provides a critical foundation for interpreting radiance, luminance, irradiance, and exitance in realistic building applications, enabling envelope designs that balance thermal control, daylight quality, and visual comfort.

1.2.3 Radiometric Measurement in the Built Environment

Radiometric measurement constitutes the empirical backbone of spectral selectivity research and application in the built environment. While radiometric quantities provide a formal description of radiative transfer, their relevance to building performance depends critically on how they are measured, interpreted, and applied under conditions representative of real buildings. In practice, radiometric measurement in building science occupies a unique position between laboratory-scale material characterization and field-scale environmental monitoring. It must capture sufficient spectral and directional detail to inform selective design, while remaining compatible with the spatial, angular, and climatic variability inherent to building operation.

Unlike many optical systems engineered for controlled illumination and fixed geometries, building envelopes interact continuously with radiation originating from multiple sources, including direct solar irradiance, diffuse sky radiation, reflected radiation from surrounding surfaces, and longwave thermal radiation exchanged with the atmosphere. These radiative components span broad wavelength ranges and vary over time, angle, and environmental conditions. As a result, radiometric measurement strategies for buildings must address not only what is being measured but also under what conditions and for what purpose. This distinction is particularly important when evaluating spectrally selective materials, whose performance cannot be adequately described by a single scalar property measured under idealized conditions.

1.2.3.1 Broadband Radiometric Measurements and Their Role in Building Practice

Broadband radiometric measurements are widely used in the building and built-environment industries because they provide a direct and practical means of quantifying total radiative exposure. Instruments




Fig. 1.5 Broadband radiometric measurement instruments.

such as pyranometers and pyrheliometers (Fig. 1.5) are routinely deployed in weather stations, test facilities, and field studies to measure global, diffuse, and direct solar irradiance on horizontal or tilted surfaces. These measurements form the basis for climate characterization, building energy simulation inputs, and code-relevant performance assessments.

From an engineering perspective, broadband measurements are particularly valuable for identifying peak conditions and cumulative exposure that drive system sizing, overheating risk, and annual energy consumption. For example, the peak solar irradiance measured on a south-facing façade during summer afternoons directly influences cooling load calculations and shading design. Similarly, cumulative broadband irradiance integrated over time informs assessments of material aging, ultraviolet exposure, and long-term thermal stress.

However, broadband measurements inherently collapse radiation across multiple spectral regions, treating visually useful and thermally detrimental radiation as a single quantity. While this aggregation is appropriate for many conventional building analyses, it obscures the wavelength-dependent behavior that spectral selectivity seeks to exploit. As a result, broadband radiometric data are best viewed as a necessary but insufficient input for the evaluation of spectrally selective envelope systems. They provide boundary conditions and performance context, but not the resolution required to distinguish selective effects.

1.2.3.2 Spectral Radiometric Measurements and Material-Level Characterization

Spectral radiometric measurements resolve radiation as a function of wavelength, preserving the information necessary to evaluate selective interaction mechanisms. In building-envelope research and practice, spectral measurements are most commonly conducted using spectroradiometers and spectrophotometers (Fig. 1.6), which quantify spectral irradiance, transmittance, and reflectance across ultraviolet, visible, and near-infrared wavelengths. These instruments enable direct observation of how envelope materials interact differently with various portions of the solar spectrum.

In the context of building applications, spectral measurements are essential for distinguishing between radiative components that serve fundamentally different functions. For example, visible radiation contributes to daylighting and visual comfort, while near-infrared radiation contributes predominantly to solar heat gain. Two materials may exhibit similar broadband solar reflectance, yet differ substantially in near-infrared reflectance, leading to markedly different thermal performance. Only spectral measurements can reveal such distinctions and support informed design decisions.




Fig. 1.6 Spectral radiometric instruments.

Spectral data also provide the foundation for calculating integrated building performance metrics, such as SHGCs and daylight transmittance, through weighted integration with standard solar spectra. Importantly, the accuracy of these derived metrics depends directly on the quality and spectral resolution of the underlying measurements. For spectrally selective materials, coarse spectral resolution or incomplete wavelength coverage can lead to misleading conclusions regarding performance effectiveness.

1.2.3.3 Measurement of Longwave Thermal Radiation and Environmental Exchange

Longwave radiometric measurement is particularly critical for evaluating thermal emission and radiative heat exchange between buildings and their environment. In contrast to shortwave solar radiation, which is externally imposed, longwave radiation is continuously emitted by building surfaces as a function of temperature and material properties. Instruments such as infrared radiometers and Fourier-transform infrared (FTIR) spectrometers are used to measure thermal radiance and spectral emissivity in the mid- and far-infrared regions (Fig. 1.7).

In building applications, longwave measurements are directly linked to surface temperature regulation, nighttime heat loss, and passive radiative cooling potential. For example, the ability of a roof or façade to emit thermal radiation effectively toward the sky depends not only on its broadband emissivity but also on how its emissivity is distributed across atmospheric transparency windows. Spectral measurements in the longwave regime are therefore essential for assessing whether a material can effectively couple with the cold sky under clear conditions. Unlike laboratory measurements of shortwave optical properties, longwave radiative behavior is strongly influenced by environmental factors such as humidity, cloud cover, and sky temperature. Consequently, laboratory-measured emissivity values must be interpreted with caution when predicting in situ performance. In building practice, longwave




Fig. 1.7 Longwave radiometric instruments.

radiometric measurements are often combined with environmental monitoring to evaluate realistic radiative exchange, highlighting the need for integrated measurement strategies that bridge material characterization and environmental interaction.

1.2.3.4 Angular Effects, Measurement Geometry, and Directional Relevance

The radiometric properties of building materials are inherently directional, yet many standard measurements are conducted under simplified geometric conditions. Solar radiation rarely impinges on building surfaces at normal incidence, and reflected or emitted radiation may exhibit strong angular dependence. As a result, measurement geometry plays a critical role in determining how well measured properties represent real building performance.

Angular-resolved radiometric measurements, often conducted using goniometric setups, provide insight into how reflectance, transmittance, and radiance vary with incidence and observation angle. These measurements are particularly important for advanced coatings, structured surfaces, and multi-layer systems, whose optical behavior may change significantly under oblique illumination. In façade applications, directional effects influence not only thermal performance but also visual appearance, glare potential, and interaction with surrounding buildings. From a building-design perspective, understanding angular dependence helps identify conditions under which spectrally selective performance may degrade or improve. Materials optimized for normal incidence may behave differently under low sun angles or diffuse sky radiation. Incorporating angular considerations into measurement and interpretation therefore enhances the robustness of spectrally selective design strategies.

1.2.3.5 Calibration, Uncertainty, and Interpretation for Building Applications

Radiometric measurements are subject to uncertainty arising from instrument calibration, detector sensitivity, spectral resolution, sample preparation, and environmental conditions. In the building domain, where materials are deployed over large areas and under variable conditions, it is often neither feasible nor necessary to achieve the extreme precision required in laboratory optics. Instead, the emphasis is placed on reproducibility, consistency, and relevance to performance outcomes.

Understanding measurement uncertainty is essential for avoiding over-interpretation of fine spectral features that may not translate into meaningful differences at the building scale. For example, minor variations in spectral reflectance at narrow wavelength bands may have a negligible impact on overall energy performance, while broader spectral trends may dominate. Effective use of radiometric measurements, therefore, requires not only technical accuracy but also engineering judgment. Standards and calibration protocols provide a common reference framework for comparing measurements across studies and applications. However, designers and engineers must remain aware of the assumptions embedded in standardized procedures and evaluate whether they align with the intended application context.

In the context of spectral selectivity, radiometric measurement should be understood as an enabling design tool rather than a passive characterization step. Measurement data inform material selection, guide envelope optimization, and validate performance predictions. By preserving spectral and directional information, radiometric measurements allow designers to align material behavior with building objectives, including energy efficiency, comfort, and sustainability. When interpreted within the broader framework of building operation and environmental interaction, radiometric measurement provides the empirical foundation upon which spectrally selective envelope strategies can be developed, assessed, and implemented at scale.

1.2.4 Metrics and Measurement Techniques in Spectral Selectivity in Building Envelopes

The practical application of spectral selectivity in building envelopes relies on a set of performance metrics that translate wavelength-dependent radiative behavior into quantities usable for design, analysis, and regulation. These metrics serve as intermediaries between detailed spectral measurements and building-scale performance evaluation. While many of these metrics are expressed as single scalar values, they are fundamentally derived from spectral radiometric and photometric principles. Understanding how these metrics relate to underlying spectral behavior is essential for interpreting their meaning, limitations, and relevance to selective envelope design. Most envelope performance metrics are intentionally simplified to support comparison, modeling efficiency, and regulatory implementation. However, this simplification often obscures spectral detail. Spectral selectivity therefore operates in a dual space: it is defined and engineered at the spectral level, but evaluated and communicated through integrated metrics. This section examines the most commonly used metrics in envelope engineering and clarifies how each reflects—or fails to reflect—spectral selectivity.

1.2.4.1 Spectral Transmittance, Reflectance, and Absorptance

Spectral transmittance, reflectance, and absorptance represent the most fundamental metrics for describing how building envelope materials interact with radiation as a function of wavelength, λ . These quantities define, at each wavelength, λ , the fraction of incident radiation that is transmitted through a material, reflected by its surface, or absorbed within it. For a material layer or system under steady-state conditions, these spectral quantities are defined as Eq. (1.20):

$$\tau(\lambda) = \frac{\Phi_t(\lambda)}{\Phi_i(\lambda)} \rho(\lambda) = \frac{\Phi_r(\lambda)}{\Phi_i(\lambda)} \alpha(\lambda) = \frac{\Phi_a(\lambda)}{\Phi_i(\lambda)} \quad (1.20)$$

where $\Phi_i(\lambda)$, $\Phi_t(\lambda)$, $\Phi_r(\lambda)$, and $\Phi_a(\lambda)$ denote the incident, transmitted, reflected, and absorbed spectral radiant flux, respectively. For opaque and semi-transparent materials in radiative equilibrium, these quantities satisfy the wavelength-by-wavelength energy conservation relationship as Eq. (1.21).

$$\tau(\lambda) + \rho(\lambda) + \alpha(\lambda) = 1 \quad (1.21)$$

This spectral partitioning forms the physical basis for all higher-level optical and thermal performance metrics used in building envelope design. In the context of spectral selectivity, these wavelength-resolved quantities are indispensable because they preserve detailed spectral information that is otherwise lost in broadband metrics. They enable direct identification of which spectral regions—ultraviolet, visible, near-infrared, or longwave infrared—are preferentially transmitted, reflected, or absorbed by a material or system. For example, a glazing system designed for cooling-dominated climates may exhibit high visible transmittance $\tau(\lambda)$ within the 380–780 nm range to support daylighting, while simultaneously maintaining low near-infrared transmittance to suppress solar heat gain. Similarly, spectrally selective coatings may achieve high solar reflectance in the shortwave infrared while maintaining tailored long-wave absorptance to control thermal emission. Such targeted spectral behavior cannot be inferred from broadband transmittance or reflectance values alone.

From a measurement perspective, spectral transmittance and reflectance are typically obtained using spectrophotometers equipped with integrating spheres to capture both specular and diffuse components under standardized geometries. Spectral absorptance is then determined indirectly through energy balance rather than measured directly. These measurements are generally performed under controlled

laboratory conditions and at near-normal incidence, providing high spectral resolution across relevant wavelength ranges. While this level of detail is essential for material characterization and design optimization, it is computationally and practically incompatible with direct use in whole-building energy simulations or regulatory frameworks.

As a result, spectral transmittance, reflectance, and absorptance primarily serve as foundational design and research metrics, rather than direct indicators of building-scale performance. They provide the raw spectral data from which integrated quantities—such as solar transmittance, solar reflectance, solar absorptance, and longwave emissivity—are derived through wavelength integration and weighting by standardized source spectra. The strength of these spectral metrics lies in their ability to reveal and quantify selective radiative behavior at its origin. Their limitation lies in the fact that they require further processing before they can be translated into metrics meaningful for energy modeling, code compliance, or comparative performance assessment. Understanding this distinction is essential for interpreting how spectral selectivity at the material level ultimately influences envelope performance at the building scale.

1.2.4.2 Solar Heat Gain Coefficient (SHGC) and Spectral Integration

The SHGC is one of the most widely used performance metrics in building envelope engineering, particularly for transparent and translucent systems such as windows, skylights, and façade glazing. SHGC represents the fraction of incident solar radiant energy that ultimately enters the building interior as heat. This includes both the portion of solar radiation that is directly transmitted through the envelope and the portion that is absorbed within the envelope and subsequently transferred indoors through conduction, convection, and longwave re-radiation. As a result, SHGC is not a purely optical quantity but a coupled radiative–thermal metric that integrates spectral radiative behavior with heat transfer processes. For practical implementation and regulatory consistency, the National Fenestration Rating Council (NFRC) adopts a simplified formulation that decomposes SHGC into two additive components, Eq. (1.22):

$$SHGC = \tau_{sol} + N \alpha_{sol} \quad (1.22)$$

where τ_{sol} is the total solar transmittance of the system, and N represents the inward-flowing fraction of absorbed solar radiation. In this standardized framework, both terms are themselves derived from spectrally integrated quantities. The total solar transmittance is calculated by integrating spectral transmittance weighted by the reference solar spectrum, while the absorbed solar energy is determined from spectral absorptance. The inward-flowing fraction N is then obtained through a further simplification based on system geometry, layer configuration, and standardized heat transfer assumptions rather than explicit wavelength-dependent heat flow modeling. This approach enables consistent and reproducible SHGC calculations across products while avoiding the computational complexity of fully coupled spectral–thermal simulations.

From a complete radiometric perspective, SHGC originates from a wavelength-resolved solar energy balance. For an incident spectral solar irradiance $E_{sol}(\lambda)$, the directly transmitted solar heat gain, Q_t , component is obtained by integrating the product of spectral transmittance and solar irradiance over the solar spectrum,

$$Q_t = \int_{\lambda} \tau(\lambda) E_{sol}(\lambda) d\lambda \quad (1.23)$$

In addition to direct transmission, a portion of the incident solar energy is absorbed within the envelope system according to its spectral absorptance $\alpha(\lambda)$. A fraction of this absorbed energy is subsequently

transferred to the indoor environment, governed by the thermal properties and boundary conditions of the system. This secondary heat gain component, Q_a , can be expressed in simplified form as Eq. (1.24):

$$Q_a = \int_{\lambda} N\alpha(\lambda)E_{sol}(\lambda)d\lambda \quad (1.24)$$

where N represents the inward-flowing fraction of absorbed solar energy. The total solar heat gain is then normalized by the total incident solar irradiance to yield SHGC.

$$SHGC = \frac{Q_t + Q_a}{\int_{\lambda} E_{sol}(\lambda)d\lambda} \quad (1.25)$$

Although SHGC is reported as a single scalar value, this formulation highlights that it is fundamentally derived through **spectral integration**, with weighting by both the solar spectrum and the envelope's wavelength-dependent optical properties.

Spectral selectivity plays a central role in shaping SHGC because different portions of the solar spectrum contribute unevenly to thermal loads and visual performance. Near-infrared radiation carries a large fraction of solar energy but contributes minimally to daylight perception, whereas visible radiation is essential for illumination but represents a smaller fraction of total solar energy. Envelope systems that selectively suppress near-infrared transmittance while maintaining high visible transmittance can therefore achieve low SHGC values without significantly compromising daylight availability. This decoupling of thermal and visual performance is a primary objective of spectrally selective glazing, coatings, and multilayer envelope systems.

Despite its practical utility, SHGC inherently obscures spectral detail. Because it aggregates wavelength-dependent behavior into a single integrated quantity, SHGC does not reveal how selectivity is achieved, nor does it distinguish between systems that rely on reflection, absorption, or spectral redistribution. Two envelope systems with identical SHGC values may exhibit markedly different spectral transmittance profiles, luminous performance, glare potential, and longwave thermal behavior. Consequently, SHGC is best interpreted as a high-level performance indicator that must be evaluated in conjunction with spectral transmittance, reflectance, and absorptance data when assessing or designing spectrally selective building envelopes.

1.2.4.3 Solar Reflectance Index and Radiative Heat Management

The Solar Reflectance Index (SRI) is a composite metric widely used to evaluate the thermal performance of opaque building envelope surfaces, particularly roofs and exterior walls. Unlike solar reflectance alone, SRI combines shortwave solar reflectance and longwave thermal emissivity into a single index intended to represent a surface's tendency to heat up under standardized solar exposure. SRI is therefore a radiatively informed metric that captures both the absorption of incoming solar radiation and the dissipation of heat through thermal emission.

From a radiometric perspective, SRI is rooted in the surface energy balance under prescribed environmental conditions. Solar reflectance determines the fraction of incident solar irradiance that is reflected, while the remaining absorbed portion contributes to surface heating. Longwave emissivity governs the rate at which the heated surface can release energy through thermal radiation. The steady-state surface temperature T_s is determined by balancing absorbed solar radiation with convective and radiative heat losses,

$$(1 - R_{sol}) G_{sol} = hc(T_s - T_a) + \epsilon \sigma (T_s^4 - T_{sky}^4) \quad (1.26)$$

where R_{sol} is the solar reflectance, G_{sol} is the incident solar irradiance, h_c is the convective heat transfer coefficient, ϵ is the longwave emissivity, and T_a and T_{sky} are the ambient air and effective sky temperatures, respectively. This formulation highlights that both shortwave and longwave radiative properties jointly determine surface thermal behavior.

The SRI normalizes the resulting surface temperature relative to two reference materials: a standard black surface (low reflectance, high emissivity) and a standard white surface (high reflectance, high emissivity). SRI is defined as Eq. (1.27):

$$SRI = 100 \times \frac{T_{black} - T_s}{T_{black} - T_{white}} \quad (1.27)$$

where T_s is the steady-state surface temperature of the material of interest, and T_{black} and T_{white} are the corresponding temperatures of the reference black and white surfaces under identical conditions. By construction, higher SRI values indicate cooler surface behavior under solar exposure, with values above 100 possible for surfaces exhibiting exceptionally high reflectance or emissivity.

Spectral selectivity plays a critical role in shaping SRI, even though SRI itself is reported as a single scalar value. Solar reflectance is determined by integrating spectral reflectance weighted by the solar spectrum, meaning that near-infrared reflectance disproportionately influences SRI due to the high energy content of this spectral region. Longwave emissivity, in turn, is governed by spectral absorptance in the thermal infrared range. Materials engineered to reflect near-infrared radiation while maintaining high thermal emissivity can achieve high SRI values without excessive visible reflectance, enabling effective radiative heat management without undesirable glare or aesthetic impacts. Despite its practical utility, SRI obscures spectral detail and dynamic thermal behavior. Different combinations of spectral reflectance and emissivity can yield similar SRI values while producing different visual appearance, aging behavior, and climatic performance. Moreover, SRI is based on standardized boundary conditions that may not represent local wind, sky temperature, or diurnal variation. As a result, SRI is best interpreted as a comparative screening metric rather than a complete descriptor of envelope thermal performance. When used in conjunction with spectral reflectance data, emissivity, SHGC, and U-factor, SRI provides valuable insight into how envelope surfaces manage radiative heat under solar loading.

1.2.4.4 U-Factor and Its Radiometric Foundations

The U-factor quantifies the overall rate of heat transfer through a building envelope assembly per unit area and per unit temperature difference between indoor and outdoor environments. It is commonly expressed as Eq. (1.28)

$$U = \frac{q}{A\Delta T} [W/m^2K] \quad (1.28)$$

where q is the steady-state heat flow through the assembly, A is the surface area, and ΔT is the temperature difference across the envelope. In building practice, the U-factor is often associated primarily with conductive and convective heat transfer through solid layers and air films. However, in many envelope systems—particularly those containing air gaps, cavities, or multilayer configurations—radiative heat transfer plays a significant and sometimes dominant role in determining the overall thermal transmittance. From a radiometric standpoint, longwave thermal radiation governs energy exchange between

facing surfaces within cavities and across surface interfaces. For two parallel surfaces at temperatures T_1 and T_2 , the net radiative heat flux can be expressed as Eq. (1.29):

$$q_{rad} = \frac{\sigma (T_1^4 - T_2^4)}{\frac{1}{\epsilon_1} + \frac{1}{\epsilon_2} - 1} \quad (1.29)$$

where σ is the Stefan–Boltzmann constant and ϵ_1 and ϵ_2 are the hemispherical longwave emissivities of the two surfaces. This formulation highlights that radiative heat exchange is strongly dependent on surface emissivity, a material property that is fundamentally defined through spectral absorptance and emittance in the thermal infrared regime. Lower emissivity directly reduces radiative heat transfer, thereby decreasing the effective thermal conductance across cavities.

In envelope assemblies such as insulated glazing units, reflective insulation systems, and ventilated façades, radiative exchange across air layers can account for a substantial fraction of total heat transfer. The introduction of low-emissivity (low-e) coatings reduces longwave emissivity and suppresses radiative coupling between surfaces, effectively lowering the overall heat transfer coefficient without increasing material thickness or altering structural configuration. This mechanism explains why low-e technologies are highly effective in reducing U-factor values despite having minimal impact on conductive heat transfer pathways.

Although the U-factor is not explicitly formulated as a spectral metric, it is indirectly shaped by spectral selectivity in the longwave infrared range. Surface emissivity is itself derived from wavelength-dependent absorptance through Kirchhoff's law of thermal radiation, linking thermal emission directly to spectral optical properties. As a result, selective control of emissivity—particularly within the 3–50 μm range relevant to building temperatures—allows envelope systems to suppress radiative heat loss while maintaining other performance objectives, such as solar transmittance or daylight availability. This relationship illustrates how radiometric principles underpin envelope performance metrics that are often perceived as purely thermal or conductive in nature. While U -factor is ultimately reported as a single scalar value for regulatory and modeling purposes, its magnitude reflects an integrated outcome of conductive, convective, and radiative heat transfer processes, with spectral radiative properties playing a critical role in advanced envelope designs.

1.2.4.5 Additional Metrics Relevant to Spectral Selectivity

Beyond conventional envelope performance metrics, a growing set of emerging indicators has been introduced to capture radiative effects that are not fully represented by integrated quantities such as SHGC, U-factor, or SRI. These include metrics such as cooling power density, net radiative heat flux, and various spectrally weighted performance indices, which are increasingly employed in research and advanced design contexts. Unlike traditional scalar metrics, these quantities often retain a more explicit connection to spectral radiometry, enabling direct assessment of how wavelength-dependent absorption, reflection, and emission contribute to thermal and energy outcomes. Such metrics are particularly valuable for evaluating emerging envelope technologies—such as radiative cooling surfaces, dynamic coatings, and multi-band selective systems—that operate outside the assumptions embedded in legacy performance frameworks.

Cooling power density and net radiative heat flux, for example, quantify the balance between absorbed solar radiation and emitted longwave radiation under specified environmental conditions. These metrics explicitly account for spectral selectivity in both the shortwave and longwave regimes and therefore

provide a more mechanistic view of envelope behavior than conventional steady-state indices. Similarly, spectrally weighted performance indices can be formulated to emphasize specific wavelength bands relevant to targeted objectives, such as near-infrared rejection, visible daylight transmission, or mid-infrared thermal emission. While these metrics are not yet standardized for regulatory use, they offer important insight into the physical processes governing advanced envelope performance.

Despite their increasing relevance, no single metric can fully describe the multifaceted role of spectral selectivity in building envelopes. Most commonly used performance metrics represent integrated outcomes that intentionally obscure spectral detail in order to support comparability, modeling efficiency, and regulatory adoption. Spectral selectivity operates beneath these metrics, shaping radiative interactions at the wavelength level before they are condensed into scalar values. For designers and engineers, the central challenge is therefore not the selection of a single “best” metric, but an understanding of what each metric captures and what it omits. Spectral metrics reveal underlying mechanisms, while integrated metrics summarize system-level outcomes. Effective application of spectral selectivity requires fluency in both perspectives, allowing envelope systems to be engineered with intentional spectral behavior while being evaluated using performance metrics compatible with building practice and policy.

References

- 1 J. Pu, C. Shen, J. Wang, Y. Zhang, C. Zhang, and S. A. Kalogirou, “Near-infrared absorbing glazing for energy-efficient windows: A critical review and performance assessments from the building requirements,” *Nano Energy*, vol. 110, 108334, Jun. 2023, doi: 10.1016/j.nanoen.2023.108334.
- 2 V. L. Lu, X. Chen, J. Chen, and K. Jiao, *Toward Energy-Efficient Buildings: Envelope Technologies and Sustainable Energy System*. Amsterdam: Elsevier, 2025.
- 3 M. Nazari, B. Matusiak, and O. Stefani, “Utilising spectral lighting simulation technique for evaluating transmitted daylight through glazing: Exploring the non-visual effects and colour appearance,” *Heliyon*, vol. 9, no. 10, e20436, Oct. 2023, doi: 10.1016/j.heliyon.2023.e20436.
- 4 A. Pierucci, A. Cannavale, F. Martellotta, and F. Fiorito, “Smart windows for carbon neutral buildings: A life cycle approach,” *Energy and Buildings*, vol. 165, pp. 160–171, Apr. 2018, doi: 10.1016/j.enbuild.2018.01.021.
- 5 CIE (International Commission on Illumination), *The Basis of Physical Photometry*. Vienna: CIE Central Bureau, 2019.
- 6 National Institute of Standards and Technology, “Realization of the candela,” NIST, 2025. [Online]. Available: <https://www.nist.gov/pml/sensor-science/optical-radiation/realization-candela>.